

CALL FOR (888) 902-2777 FOR INSTALLATION QUESTIONS OR EMAIL INFO@EX-GUARD.COM



1. SURFACE PREPARATION:

Follow Bondo Kit instructions for prepping surface and applying the Bondo mixture.

2. PRIME/PAIN:

After sanding until smooth, clean entire surface prior to painting.

Finally, use the included color matched paint following the instructions on the can.

IMPORTANT: Be sure to follow the steps on the can in exact order to ensure the best finish

