

(1) LOCATE AND REMOVE THE CLEVIS TOW LOOP, BY; REMOVING THE FOUR NUTS AS SEEN IN THE PICTURES BELOW. PULL THE BUMPER FORWARD AND REMOVE THE COTTER PIN AND PULL THE 1 INCH PIN OUT OF THE CLEVIS. SAVE CLEVIS FOR TOWING, BY REATTACHING TO MOUNTING BRACKET. REPEAT FOR OTHER SIDE.

INSIDE THE BUMPER




IN FRONT OF THE BUMPER



REATTACH CLEVIS TO BRACKET



(2) INSTALL THE MOUNTING BRACKETS AS SHOWN BELOW BY POSITIONING ON THE OUTSIDE OF THE FRAME, BACK OF BRACKET SHOULD REST AGAINST THE BUMPER BRACKET RIVITED TO THE FRAME.



IMPORTANT!! Any Ex-Guard grille guard, bracket kit, or hardware must be used with corresponding Ex-Guard components. Use of any other product or brand with Ex-Guard products will immediately void the warranty provided by Ex-Guard Industries.








BOLT KIT - XG-BRK13 & XG-BRK23

COMPATIBLE GUARDS

• Check https://ex-guard.com/





ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	XG-24DMA-BR10	MOUNTING BRACKET	2
2	XG-001-100-8HHC3008ZY	1" X 3" HEX HEAD CAPSCREW	2
3	XG-001-100-8HHNTL8ZY	1"-8 TOP LOCK HEX NUT	2
4	XG-001-62-11FHHNL5Z	5/8-11 FLANGE PATCH HEX NUT	8

ATTENTION!! Any Ex-Guard grille guard, bracket kit, or hardware must be used with corresponding Ex-Guard components. Use of any other product or brand with Ex-Guard products will immediately void the warranty provided by Ex-Guard Industries.